


# TECHNICAL INFORMATION SHEET

No. 0609-01  
13-Jun-05



## CINO XS PB E2 (Standard) Ingredients Portioning Guide

This information provides an approximate guide to the settings for the ingredient, water & mixer timers to achieve larger drink sizes. The suggested settings are proportionately calculated from the default settings in the machine.

**Note:** This information is only meant as a general guide to increasing drink sizes, the overall taste of the drink is dependant on the ingredients used and individual's preferences. It should be further noted that the coffee content is limited by the doser size. Therefore the strength and quality of larger drinks will be affected.

	Machine Default	7oz cup	9oz cup
<b>Cappuccino</b>			
Coffee water	40	52	60
Product 2 (milk)	3.0	3.9	4.5
Water 2	5.5	9.3	11.0
Mixer 2	7.0	11.3	13.0

<b>Latte Macchiato</b>			
Coffee water	30	39	45
Product 2 (milk)	5.0	6.5	7.5
Water 2	6.5	11.0	13.0
Mixer 2	5.0	9.0	11.0
Mixer 2 start time	4.0	4.0	4.0

<b>Espresso</b>			
Coffee water	30	n/a	n/a

<b>MoccaCino</b>			
Coffee water	40	52	60
Product 2 (milk)	3.0	3.9	4.5
Product 3 (choc)	1.7	2.2	2.6
Water 2	5.5	7.2	11.0
Mixer 2	7.0	9.2	13.0

	Machine Default	7oz cup	9oz cup
<b>Black Coffee</b>			
Coffee water	110	143	100
Water 1 Time	0.0	0.0	7.0

<b>Café Au Lait</b>			
Coffee water	60	78	90
Product 2 milk	2.5	3.3	3.8
Water 2	3.5	5.9	7.0
Mixer 2	5.0	7.9	9.0

<b>Hot Chocolate</b>			
Product 3 (choc)	4.4	5.7	6.6
Water 2	8.0	13.6	16.0
Mixer 2	10.0	15.6	18.0

<b>Hot water</b>			
Water 1	9.0	14.6	17.0

The 7oz and 9oz settings are available in rreaction file format and can be downloaded to a machine using our flash key system. Please enquire about the options available.