

TECHNICAL INFORMATION SHEET

No. 0609-02
13-Jun-05



CINO XS PB E2 (PLUS) Ingredients Portioning Guide

This information provides an approximate guide to the settings for the ingredient, water & mixer timers to achieve larger drink sizes. The suggested settings are proportionately calculated from the default settings in the machine.

Note: This information is only meant as a general guide to increasing drink sizes, the overall taste of the drink is dependant on the ingredients used and individual's preferences. It should be further noted that the coffee content is limited by the doser size. Therefore the strength and quality of larger drinks will be affected.

	Machine Default	7oz cup	9oz cup
Cappuccino			
Coffee water	40	52	60
Product 2 (milk)	3.0	3.9	4.5
Water 1	5.5	9.3	11.0
Mixer 1	7.0	11.3	13.0

Espresso			
Coffee water	30	Na	Na

Café Au Lait			
Coffee water	60	78	90
Product 2 (milk)	2.5	3.3	3.8
Water 1	3.5	5.9	7.0
Mixer 1	5.0	7.9	9.0

MoccaCino			
Coffee water	40	52	60
Product 1 (choc)	1.7	2.2	2.6
Product 2 (milk)	3.0	3.9	4.5
Water 1	5.5	7.2	11.0
Mixer 1	7.0	9.2	13.0

	Machine Default	7oz cup	9oz cup
Black Coffee			
Coffee water	110	143	165

Latte Macchiato			
Coffee water	30	39	45
Product 2 (milk)	5.0	6.5	7.5
Water 1	6.5	11.0	13.0
Mixer 1	5.0	9.0	11.0
Mixer 1 start time	4.0	4.0	4.0

Hot Chocolate			
Product 1 (choc)	4.4	5.7	6.6
Water 1	8.0	13.6	16.0
Mixer 1	10.0	15.6	18.0

Black Tea – (Machine default *)			
Product 3	3.0	3.9	4.5
Water 2	8.0	13.6	16.0
Mixer 2	10.0	15.6	18.0

* For alternative drinks on selection 8 (e.g. white tea, decaffeinated coffee or soup) see information sheet 0609-03 for program settings.